



# PVC BIGBUILD CEILING BOARD 7mm

distributed by   
plastic sales  
plumbing sales

## INSTALLATION INSTRUCTIONS

- Ensure the same batches are used in the same areas. A slight variation between productions may occur.
- Make sure your bandering are 50cm apart.
- Make sure your panels face in the same direction. Fasten the screw head flush with the groove of the ceiling panel, into the bandering .
- Clip the second panel with the tongue, into the groove of the first panel ,using only the palm of your hand.
- Make sure it is correctly in place before screwing the screw into the groove
- Carry on with the previous step until the area is completed.
- You can use a Stanley (carpet) knife, to cut the last ceiling panel if needed.
- Install cornices to finish off. If dirty, use damp cloth or sponge, with warm soapy water to clean ceiling boards.
- Carries a 5 Year warranty .

## ADVANTAGES OF BIGBUILD CEILING BOARDS

Easy to Install with no mess  
UV Protected - can be exposed to light (unlike similar products in the market)  
Low Maintenance  
Water & Moisture Resistant  
Highly recommend for kitchens, bathrooms & patios - no algae problems  
Non Flammable  
Excellent Insulation

FACTORY  
RATINGS

